VOLLRATH®
Setting the Standard™

Operator's Manual

VOLLRATH®
REDCO®

EaziClean® Can Opener
Premium™ Can Opener

| BCO-2000 |
| BCO-3000 |

| BCO-5000 |
| BCO-6000 |

| BCO-7000 |

| BCO-1 |

Product Number	Description
BCO-2000	EaziClean® 16" Bar Length, 1" Gear
BCO-3000	EaziClean® 25" Bar Length, 1" Gear
BCO-5000	EaziClean® 16" Bar Length, 1-1/2" Gear
BCO-6000	EaziClean® 25" Bar Length, 1-1/2" Gear
BCO-7000	EaziClean® 25" Bar Length, 1-1/2" Gear
BCO-1	Preimum™ 16" Bar Length, 1" Gear

Thank you for purchasing this Vollrath Food Processing Equipment. Before operating the equipment, read and familiarize yourself with the following operating and safety instructions. SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE. Save the original box and packaging. Use this packaging to ship the eequipment if repairs are needed.

SERVICE AND REPAIR

Please contact the qualified professional repair service listed below.

VOLLRATH Induction Repair Service • 1-800-825-6036 (USA) or www.vollrathco.com

When contacting the Authorized Professional Service Center, please be ready with the model number, serial number, and proof of purchase showing the date the unit was purchased.

SPARE PARTS LIST AND DIAGRAM - PREIMUM™

Callout	Part Number	Description
1	116	Handle Assembly (for BCO-1)
2	125	Collar Washer (for BCO-1)
3	122	Collar (for BCO-1)
4	BCO-11	Blade (for BCO-1)
5	BCO-12	1" Gear (for BCO-1)
6	BCO-3	Base (for BCO-1)
7	N/A	Screws
8	N/A	Washers
9	N/A	Bar

SPARE PARTS LIST AND DIAGRAM - EAZICLEAN®™

Callout	Part Number	Description
1	379080	Handle Assembly (for BCO-2000 and BCO-3000)
1	379093	Handle Assembly (for BCO-5000 and BCO-6000)
1	379094	Handle Assembly (for BCO-7000)
2	122	Collar Washer (for BCO-2000 and BCO-3000)
2	379095	Collar Washer (for BCO-5000, BCO-6000, BCO-7000)
3	379082	Collar (for BCO-2000 and BCO-3000)
3	379096	Collar (for BCO-5000, BCO-6000, BCO-7000)
4	379083	Spring (for BCO-2000 and BCO-3000)
4	379097	Spring (for BCO-5000 and BCO-6000)
4	379098	Spring (BCO-7000)
5	BCO-12	1" Gear (for BCO-2000and BCO-3000)
5	BCO-10	1-1/2" Gear (for BCO-5000, BCO-6000, BCO-7000)
6	BCO-15	Quick Release Replacement Cartridge (for BCO-2000 and BCO-3000)
6	BCO-14	Quick Release Replacement Cartridge (for BCO-5000, BCO-6000, BCO-7000)
7	BCO-16	Blade Screws and O-Ring Washers
8	BCO-11	Blade
9	BCO-3	Base
10	379090	Clamp
11	379089	Base and Clamp (Includes (Ref. Nos. 9 and 10)
12	379099	Bushing (for BCO-5000, BCO-6000, BCO-7000)
13	N/A	Bar